LED Outdoor Luminaires Wall Mount Installation Instructions

SAFETY PRECAUTIONS

- Read all safety precautions and installation instructions carefully before installing or servicing this fixture. Failure to comply with these instructions could result in potentially fatal electric shock and/or property damage.
- It is recommended that a qualified electrician perform all wiring. This fixture must be wired in accordance with all national and local electrical codes.
- . Do not handle any energized fixture or attempt to energize any fixture with wet hands or while standing on a w et or damp surface or in water.
- This fixture is designed for use in a 120-277VAC, 50/60Hz fused circuit. The fixture can be dimmable.
- To reduce the risk of electrical shock, and to assure proper operation, this fixture must be adequately grounded. To accomplish proper grounding, there must be a separate
 ground wire (green) contact between this fixture and the ground connection of your main power supply panel.
- This fixture is intended to be used for general outdoor lighting in wet locations, mounted at least 48 inches above the ground level.
- Disclaimer

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules and Canadian ICES -005 (B) / NMB-005 (B). These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- · Reorient or relocate the receiver antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult with the dealer or an experienced radio/TV technician for help.

Any modifications to this fixture may void the warranty and interfere with the safe operation of the luminaire.

Operation is subject to the following two conditions: (1) this device may not cause interference, and (2) this devic e must accept any interference, including interference that may cause undesired operation of the device.

• MIN 90°C SUPPLY CONDUCTORS LES FILS D'ALIMENTATION 90°C MIN.

ASSEMBLY INSTRUCTIONS

- (1) Take out two screws 1 2 , and then remove back plate 3 from the fixture.
- (2) Install back plate ③ to junction box (not provided) by securing it with two screws ④.
- (3) Install half-round frame $\ensuremath{\mathfrak{D}}$ to back plate $\ensuremath{\mathfrak{I}},$ and then tighten two screws $\ensuremath{\mathfrak{D}}$ $\ensuremath{\mathfrak{D}}.$
- (4) Seal the gap on the top,left and right side of the fixture, make sure fixture and wall are sealed together by silicon.

COLOR CHANGING TEMPERATURE ADJUSTMENT, CCT (IF DESIRED).

- (1) Adjust CCT switches on each board accordingly to the desired color temperature as seen below.All boards must be set the same way.
- (2) Note:Fixture is preset to 3000K from factory. Power to fixture must always be turned OFF prior to adjusting CCT switches.

COLOR TEMPERATURE ADJUSTMENT SETTING







